



## More info about Recommended Crankcase oil

Recommended oil:

- [7915.151 - One Litre](#)
- [7915.155 - Five Litres](#)

### US

Genuine Cat Pumps Oil, custom blend :

- Hydraulic oil V.G 68 and V.I 135
- additives against wear, oxidation, corrosion and rust

### Europe

- hydraulic oil V.G 100 and V.I 130 as minimum V.I value
- additives against wear, oxidation, corrosion and rust
- high shear resistance or EP additives

### Be careful when selecting oil !!

Similar oil names can have big difference in V.I factor.

Example:

Texaco Rando HD 100 hydraulic oil has V.I 97 NOT RECOMMENDED

**Texaco Rando HDZ 100** hydraulic oil has V.I 145 **RECOMMENDED**

Today, with the new developments in multigrade motor oils, it is possible to replace a hydraulic oil by a multigrade oil. These oils have a high shear resistance, are stable at varying min/max temperature, have high oxidation resistance.

Specifications: 15W40

V.G +/- 100 with high flow ability

V.I > 130

Brands: Total / Shell / BP / Mobil ...



# PIJTTERSEN

Pijttersen B.V.  
Stavangerweg 14A  
9723 JC Groningen  
Tel. : +31 (0)50-8200963  
BTW: NL002166811B01

KVK: 01013855  
BIC: ABNANL2A  
IBAN: NL56ABNA0482164727  
E-Mail: [info@pijttersen.nl](mailto:info@pijttersen.nl) / [info@catpumps.nl](mailto:info@catpumps.nl)  
Internet: [www.pijttersen.nl](http://www.pijttersen.nl) / [www.catpumps.nl](http://www.catpumps.nl)